Menutree Website:

- + Products / docu / downloads
 - + Accessories
 - + Connector plug / equipment
 - + MPI- / Profibus connecting cable (for







Please make sure to update your drivers before using our products.

Detect failure of Profinet-devices




Identify devices that are likely to fail in the near future.

Detect defective devices that no longer respond to PN protocols.

Defective devices are reported by email and logged.

No long troubleshooting thanks to exact station information.

Programming of S7-PLC-devices via LAN



S7-PLC with PPI, MPI, Profibus connection, but data should be read/written via network?

Ethernet-CP cannot be used because of the effort (hardware-configuration), price, space in the rack, availability. Plug S7-LAN-module/MPI-LAN-cable into a free bus-connector, assign the IP-address and the PLC can be reached via the network. There is no need to invest any more effort. The adapter can be parameterized via an integrated web-server or a configuration-tool. No changes to the S7-PLC are necessary to operate the adapter.

The adapter can also be used to implement PUT/GET-connections to other controls, but the PLC-program must be changed for this. Other PLCs can just as well read/write data from this controller via PUT/GET; nothing needs to be changed in the PLC program.

Automation very easy: Connect, parameterize and work.


Management of the IP address

IP-Zugriffsschutz			
Schutzmodus:	IPs aus Liste verbiete	n v	
IP-Adresse / IP-Bereich #1:	192.168.178.10	 -	Bereich (optional)
IP-Adresse / IP-Bereich #2:	192.168.178.100		192.168.178.200
IP-Adresse / IP-Bereich #3:	192.168.178.254		Bereich (optional)
IP-Adresse / IP-Bereich #4:			Bereich (optional)
IP-Adresse / IP-Bereich #5:			Bereich (optional)
IP-Adresse / IP-Bereich #6:			Bereich (optional)
IP-Adresse / IP-Bereich #7:			Bereich (optional)
IP-Adresse / IP-Bereich #8:			Bereich (optional)
IP-Adresse / IP-Bereich #9:			Bereich (optional)
IP-Adresse / IP-Bereich #10:			Bereich (optional)
IP-Adresse / IP-Bereich #11:			Bereich (optional)
IP-Adresse / IP-Bereich #12:			Bereich (optional)
IP-Adresse / IP-Bereich #13:			Bereich (optional)
IP-Adresse / IP-Bereich #14:			Bereich (optional)
IP-Adresse / IP-Bereich #15:			Bereich (optional)

The IP filter is used to determine whether or not the entered IP-addresses or IP-address-ranges may communicate with the connected controllers via the module.

The list can be edited centrally be switched with a button from "allowed" on "not allowed".

Linking of S5-PLC's without modifying the PLC-program




You have to link several S5-PLC's so that in case of need you can respond to all of them without modifying the PLC-program? No problem, connect all PLC's that are in the run with the IBX-Klemme, set up the respective address (1 to 30) at the IBX-Klemme and with the address 0 you will be able to respond to all PLC's via PD-bus-path selection.

Remote maintenance / telecontrol of PLC




The access to the connected PLC with the Siemens TS-software or PG-2000 including TS-option results of coupling via Analogue-, ISDN- (only with AB-adapter) as well as GSM-line.

Integrated phone-book



You have to consider several facilities and do not want to keep a watch list with phone numbers? No problem, the TELE-router contains a phone book, so you any time maintain the entire data connection in the router and build to the opposite side by clicking the link in the web browser.

S7-300/400 (MPI/DP) to S7-300/400 (MPI/DP)



 $Coupling \ S7-controller \ with \ MPI/Profibus \ at \ S7-controller \ with \ MPI/Profibus \ via \ network$