

Step5/7-Programming system PG-2000

Installation note:

Load your license file using the link given in your personal license email. The password for extraction can also be found in this email. Then copy this file into the folder of the installed PG-2000 software (demo version). After restarting the software, your license is active.

<https://www.tpa-partner.de>

Menutree Website:

- + Products / docu / downloads
- + Software
- + Programming-software PG-2000 Step:
- + Basic packages AWL

QR-Code Website:




```

NETWORK 1 USD 0 HELLFHEIKPROGRAMMT
|EN| -Merkez50_0
|EN| CT 8084_0
|EN| ST 000_0
|EN| ST 000_0
|EN| -Merkez50_0
|EN| -Merkez50_0
Name: SPB_PB_20
Name: SPB_PB_20
Name: SPB_PB_20
Name: SPB_PB_20
  
```


Please make sure to update your drivers before using our products.

Direct-mode „extended serial interface“




There is an unsupported control or data logger or converter integrated in your installation which protocol is not supported? No problem, the signs that the PC in the office sends will be transferred via telephone line by the Direct-mode, and on-site reproduced by the TP/TB. The way back is identical. So in that case there's also a communication to the electronic devices available.

PLC-coupling (data exchange between PLC-devices)




Your pumping stations report the water levels of the central control via telephone network. The central office itself can of course transmit commands/messages to the substations as well. Thereto no dedicated line is required, it's sufficient when the stations connect via network (DSL-router).

Interface-switch for PD/PC




You have to work with more PLC-devices, but no pleasure to switch on/off? No problem, you connect a device of the AG-Switch-family to the PLC-devices and your PD/PC and you will be able to communicate to both PLCs. The selection which PLC you make for AG-Switch-I via toggle switch and for the AG-Switch-II via 24V-controll input.

Operation on DSL-cable-modem




You are looking for a device which can be operated even with DSL? No problem, just plug in your TELE-router to a DSL cable modem, enter the parameters relating to the access data into the device and you are connected to Internet.

S7-CP-replacement (without LAN-CP to the PLC-device)



Do you have a S7-PLC-device without CP243-1, CP343-1 or CP443-1 and would like to connect via LAN? Then plug the S7-LAN on the PLC-device and your access via RFC1006 is ready for use.

Wireless around the S7-PLC



Move wirelessly around the S7-PLC and communicate for example ONLINE in the status